

SW2, SW2-US Auxiliary Switch Kit for HVAC Damper Actuators MNXX20, MNXX34, MSXX10A, MSXX20A

INSTALLATION INSTRUCTIONS

<p>1</p> <p>Ø = 4 ... 000 AWG (5 ... 10 mm) 100 Vac, 5 (3) A 2-3/8 - 3-1/8 in. (60 - 80 mm) 3/16 in. (5 mm)</p> <p>A B</p> <p>M25331</p>	<p>2</p> <p>B A</p> <p>M25332</p>	<p>3 (MSXX05A, MSXX10A, MSXX20A)</p> <p>M25333</p>
<p>4</p> <p>Ø = 4 ... 000 AWG (5 ... 10 mm) 100 Vac, 5 (3) A 2-3/8 - 3-1/8 in. (60 - 80 mm) 3/16 in. (5 mm)</p> <p>A B</p> <p>M25331</p>	<p>5</p> <p>24 V + 24 V ✓</p> <p>M25335</p>	<p>6</p> <p>A or A B C</p> <p>M25336</p>
<p>7</p> <p>A B C 20 mm 6 Nm</p> <p>M25337</p>	<p>8</p> <p>AS1 AS2</p> <p>A — S3 S6 — C B — S1 S4 — C S2 S5 — D</p> <p>45 90 0 0</p> <p>A C B D</p> <p>M25338</p>	<p>9 Setting AS1, AS2</p> <p>10-15</p> <p>M25339</p>



<p>10 Setting AS1 (e.g. to 30°)</p> <p>M25340</p>	<p>11</p> <p>M25341</p>	<p>12 Result (10 + 11)</p> <p>M25342</p>
<p>13 Setting AS2 (e.g. to 75°)</p> <p>M25343</p>	<p>14</p> <p>M25344</p>	<p>15 Result (13 + 14)</p> <p>M25345</p>
<p>16</p> <p>M25346</p>	<p>E resultsetting e. g. to D ergebniseistellen z. b. auf DKresultatjustering f. eks ESresultadoajuste e. g. en F résultatajustment p. a. au I risultatoaggiustaggiop. e. in N resultatjustering f. eks NLresultatinstellen b. v. S resultatinställning ex. FI tulos aseta esim</p>	

By using this Honeywell literature, you agree that Honeywell will have no liability for any damages arising out of your use or modification to, the literature. You will defend and indemnify Honeywell, its affiliates and subsidiaries, from and against any liability, cost, or damages, including attorneys' fees, arising out of, or resulting from, any modification to the literature by you.

Automation and Control Solutions

Honeywell International Inc.
 1985 Douglas Drive North
 Golden Valley, MN 55422
 customer.honeywell.com



© U.S. Registered Trademark
 © 2011 Honeywell International Inc.
 62-0259-03 M.S. Rev. 10-11
 Printed in United States