

VG2000 Series Cast Iron Flanged Globe Valves, Maintenance and Repair

Selection Chart

0-4-	Selection Chart		
Code Number	Description	Ship Weight, Ib ¹	
Packing Kits			
V-9999-613	For 2-1/2 through 4 in. Valves with 3/8 in. Stem. Kit Includes: Two Ring Packs (U-Cup with O-Ring Installed), One Follower, One Spacer, Insertion/Removal Tool, One Grease Tube, and One 3 in. (76 mm) Strip of Crocus Cloth.	0.1	
V-5252-668	For 3 through 6 in. Valves with 1/2 in. Stem. Kit Includes: Two Ring Packs (U-Cup with O-Ring Installed), One Follower, One Spacer Insertion/Removal Tool, One Grease Tube, and One 3 in. (76 mm) Strip of Crocus Cloth.	0.2	
Packing Nut I	(its (Pneumatically Actuated Assembles Only)	l .	
V-4510-6019	For 2-1/2 through 4 in Valves with 3/8 in. Stem	0.1	
V-5252-609	For 3 through 6 in. Valves with 1/2 in. Stem	0.4	
Valve Recond	litioning Kits	l .	
V-5252-6001	Reconditioning Kit, 2-1/2 in. N.O. Flanged Valve, M Stem (3/8 in.), for Use with MP84 Pneumatic Actuator or Electric Actuator, Cv = 51.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	7.0	
V-5252-6002	Reconditioning Kit, 2-1/2 in. N.O. Flanged Valve, L Stem (3/8 in.), for Use with MP82 Pneumatic Actuator, Cv = 51.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	6.9	
V-5252-6003	Reconditioning Kit, 3 in. N.O. Flanged Valve, M Stem (3/8 in.), for Use with MP84 Pneumatic Actuator or Electric Actuator, Cv = 83.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	9.5	
V-5252-6004	Reconditioning Kit, 3 in. N.O. Flanged Valve, L Stem (3/8 in.), for Use with MP82 Pneumatic Actuator; Cv = 83.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	9.5	
V-5252-6005	Reconditioning Kit, 4 in. N.O. Flanged Valve, M Stem (3/8 in.), for Use with MP84 Pneumatic Actuator or Electric Actuator, Cv = 150.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, Grease Packet.	15.0	
V-5252-6006	Reconditioning Kit, 4 in. N.O. Flanged Valve, N Stem (1/2 in.), for Use with MP86 Pneumatic Actuator, Cv = 150.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	16.5	
V-5252-6007	Reconditioning Kit, 5 in. N.O. Flanged Valve, N Stem (1/2 in.), for Use with MP86 Pneumatic Actuator, Cv = 240.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	22.0	
V-5252-6008	Reconditioning Kit, 6 in. N.O. Flanged Valve, N Stem (1/2 in.), for Use with MP86 Pneumatic Actuator, Cv = 350.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	30.6	
V-5462-6001	Reconditioning Kit, 2-1/2 in. N.C. Flanged Valve, M Stem (3/8 in.), for Use with MP84 Pneumatic Actuator or Electric Actuator, Cv = 54.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	7.4	
V-5462-6002	Reconditioning Kit, 3 in. N.C. Flanged Valve, M Stem (3/8 in.), for Use with MP84 Pneumatic Actuator or Electric Actuator, Cv = 83.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	9.9	
V-5462-6003	Reconditioning Kit, 3 in. N.C. Flanged Valve, N Stem (1/2 in.), for Use with MP86 Pneumatic Actuator, Cv = 83.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	12.7	
V-5462-6004	Reconditioning Kit, 4 in. N.C. Flanged Valve, M Stem (3/8 in.), for Use with MP84 Pneumatic Actuator or Electric Actuator, Cv = 150.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, Grease Packet.	16.3	
V-5462-6005	Reconditioning Kit, 4 in. N.C. Flanged Valve, N Stem (1/2 in.), for Use with MP86 Pneumatic Actuator, Cv = 150.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	17.4	
V-5462-6006	Reconditioning Kit, 5 in. N.C. Flanged Valve, N Stem, (1/2 in.), for Use with MP86 Pneumatic Actuator, Cv = 237.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	23.7	
V-5462-6007	Reconditioning Kit, 6 in. N.C. Flanged Valve, N Stem (1/2 in.), for Use with MP86 Pneumatic Actuator, Cv = 344.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	31.1	
V-5842-6001	Reconditioning Kit, 2-1/2 in. Three-Way Mixing Flanged Valve, \mathbf{M} Stem (3/8 in.), for Use with MP84 Pneumatic Actuator or Electric Actuator, $Cv = 54.0$; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	8.1	
V-5842-6002	Reconditioning Kit, 3 in. Three-Way Mixing Flanged Valve, M Stem (3/8 in.), for Use with MP84 Pneumatic Actuator or Electric Actuator, Cv = 80.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	10.8	
V-5842-6003	Reconditioning Kit, 3 in. Three-Way Mixing Flanged Valve, N Stem (1/2 in.), for Use with MP86 Pneumatic Actuator, Cv = 80.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	12.3	
V-5842-6004	Reconditioning Kit, 4 in. Three-Way Mixing Flanged Valve, for Use with Electric Actuator, Cv = 157.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	16.6	
V-5842-6005	Reconditioning Kit, 4 in. Three-Way Mixing Flanged Valve, N Stem (1/2 in.), for Use with MP86 Pneumatic Actuator, Cv = 157.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	17.8	
V-5842-6006	Reconditioning Kit, 5 in. Three-Way Mixing Flanged Valve, N Stem (1/2 in.), for Use with MP86 Pneumatic Actuator, Cv = 238.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	22.0	
V-5842-6007	Reconditioning Kit, 6 in. Three-Way Mixing Flanged Valve, N Stem (1/2 in.), for Use with MP86 Pneumatic Actuator, Cv = 347.0; Includes: Bonnet and Packing Items, Stem and Disk Assembly, Packing Tools, Gasket and Screw Set, and Grease Packet.	31.9	

^{1.} $lb \times 0.454 = kg$.