

Inner Valve Reconditioning Kits: 3/4 to 2 in.

Description

The available parts listed in the Selection Chart can extend the service life of the valve series listed and return the valves to near original operating performance.

Note: For VG7000 Reconditioning Kits, refer to the *VG7000 Series Bronze Globe Valves, Maintenance and Repair Catalog Page (LIT-1924275)*.

Selection Chart

Valve Body	Valve Size, in.	Spring Range, psig	Inner Valve Kit Code Number
V-3752	3/4 UA	3 to 6 or 9 to 13	V-3752-6016 or V-3752-6027
V-3752	1 UA	3 to 6 or 9 to 13	V-3752-6017 or V-3752-6028
V-3752	1-1/4 UA	3 to 6 or 9 to 13	V-3752-6018
V-3752	1- 1/4 UG	3 to 6 or 9 to 13	V-3752-6019
V-3752	1-1/2 UA	3 to 6 or 9 to 13	V-3752-6020 or V-3752-6030
V-3752	2	3 to 6 or 9 to 13	V-3752-6034 or V-3752-6031
V-3800	3/4 UA	3 to 6	V-3800-6001
V-3754-1008	3/4	9 to 13	V-3754-6001
V-3754-1022	3/4	3 to 6	V-3754-6001
V-3754-1026	3/4	3 to 6	V-3754-6001
V-3754-4001	3/4	3 to 6	V-3754-6001
VB-3754-4	3/4		V-3754-6001
VB-3754-4014	3/4		V-3754-6001
V-3754-1010	1	9 to 13	V-3754-6002
V-3754-1023	1	3 to 6	V-3754-6002
V-3754-1027	1	3 to 6	V-3754-6002
V-3754-4002	1	3 to 6	V-3754-6002
VB-3754-5	1		V-3754-6002
VB-3754-8	1-1/4		V-3754-6002
V-3974-1004	3/4	9 to 13	V-3974-6001
V-3974-1010	3/4	9 to 13	V-3974-6001
V-3974-2004	3/4	9 to 13	V-3974-6001
V-3974-4001	3/4	9 to 13	V-3974-6001
VB-3974-4	3/4		V-3974-6001
VB-3974-1005	1		V-3974-6002
V-3974-1011	1	9 to 13	V-3974-6002
V-3974-2005	1	9 to 13	V-3974-6002
V-3974-4002	1	9 to 13	V-3974-6002
V-4324-1005	3/4	4 to 8	V-4324-6001
V-4324-1006	3/4	9 to 13	V-4324-6001
V-4324-1013	3/4	9 to 13	V-4324-6001
V-4324-4001	3/4	4 to 8	V-4324-6001
V-4324-4003	3/4	9 to 13	V-4324-6001
V-4324-4014	3/4		V-4324-6001
VB-4324-4	3/4		V-4324-6001
V-4324-1007	1	4 to 8	V-4324-6002
V-4324-1008	1	9 to 13	V-4324-6002
V-4324-1014	1	9 to 13	V-4324-6002
V-4324-4002	1	4 to 8	V-4324-6002
V-4324-4004	1	9 to 13	V-4324-6002
VB-4324-5	1		V-4324-6002
VB-4324-8	1-1/4		V-4324-6002

Valve Body	Valve Size, in.	Spring Range, psig	Inner Valve Kit Code Number
V-3754-1028	1-1/2	3 to 6	V-5254-6001
V-3754-1029	1-1/2	9 to 13	V-5254-6001
V-3754-1030	1-1/2	3 to 6	V-5254-6001
VB-3754-6	1-1/2		V-5254-6001
V-5254-1	1-1/2	2 to 5	V-5254-6001
V-5254-11	1-1/2	2 to 5	V-5254-6001
V-5254-2	1-1/2	2 to 5	V-5254-6001
V-5254-3	1-1/2	9 to 13	V-5254-6001
VB-3754-7	2		No kits available, replace valve
V-5254-4	2	9 to 13	
V-5254-5	2	2 to 5	
V-5254-6	2	9 to 13	
V-5254-12	2	2 to 5	
V-3974-1012	1-1/2	9 to 13	V-5464-6001
V-3974-1013	1-1/2	9 to 13	V-5464-6001
VB-3974-6	1-1/2		V-5464-6001
V-5464-1	1-1/2	9 to 13	V-5464-6001
V-5464-11	1-1/2	9 to 13	V-5464-6001
V-5464-2	1-1/2	9 to 13	V-5464-6001
VB-3974-7	2		No kits available, replace valve
V-5464-3	2	9 to 13	
V-5464-4	2	9 to 13	
V-5464-12	2	9 to 13	
V-4324-1015	1-1/2	4 to 8	V-5844-6001
V-4324-1016	1-1/2	9 to 13	V-5844-6001
V-4324-1017	1-1/2	9 to 13	V-5844-6001
VB-4324-6	1-1/2		V-5844-6001
V-5844-1	1-1/2	4 to 8	V-5844-6001
V-5844-2	1-1/2	9 to 13	V-5844-6001
V-5844-2	1-1/2	9 to 13	V-5844-6001
V-5844-11	1-1/2	9 to 13	V-5844-6001
VB-4324-7	2		No kits available, replace valve
V-5844-4	2	4 to 8	
V-5844-5	2	9 to 13	
V-5844-6	2	9 to 13	
V-5844-12	2	9 to 13	