

Technical data sheet

Z2100QPF-K

ZoneTight™, 2-way, Press fit

• For closed cold and warm water systems

• For switching functions and 2-point controls on the water side of air-handling units and heating systems

• Snap-assembly of the actuator





| | /er | | |
|--|-----|--|--|
| | | | |
| | | | |
| | | | |

| Туре | DN |
|------------|----|
| Z2100QPF-K | 25 |
| | |

Technical data

| Functional data | Valve size [mm] | 1" [25] | |
|--------------------|-----------------------------|---|--|
| | Fluid | chilled or hot water, up to 60% glycol | |
| | Fluid Temp Range (water) | 2100°C [36212°F] | |
| | Close-off pressure ∆ps | 75 psi | |
| | Differential pressure Δpmax | 40psi | |
| | Flow characteristic | equal percentage | |
| | Leakage rate | 0% | |
| | Angle of rotation note | Operating range 1590° | |
| | Pipe connection | Press fit | |
| | Installation orientation | upright to horizontal (in relation to the stem) | |
| | Servicing | maintenance-free | |
| | Flow Pattern | 2-way | |
| | Controllable flow range | 75° | |
| | Cv | 8.2 | |
| Materials | Valve body | forged brass | |
| | Stem | brass | |
| | Stem seal | EPDM O-ring | |
| | Seat | PTFE, O-Ring EPDM | |
| | Ball | chrome plated brass | |
| Suitable actuators | Non Fail-Safe | CQB(X) | |
| | Electrical fail-safe | CQKB(X) | |

Safety notes



WARNING: This product can expose you to lead which is known to the State of California to cause cancer and reproductive harm. For more information go to www.p65warnings.ca.gov
If temperature exceeds 212°F operating range due to a boiler control failure the valve will

safely contain the hot water but manufacturers product warranty becomes invalid. Valve and actuator replacement is at the expense of others.



| Product features | |
|------------------------|--|
| Application | The QCV zone valves are suited for large commercial buildings where higher close-off and the ability to change flow is desired. Common applications include unit ventilators, fan coil units, VAV reheat coils, fin tube casing, radiant panels and duct coils. The valve fits in space restricted areas and can be assembled without the use of tools. |
| Operating mode | The ball valve is adjusted by a rotary actuator. The rotary actuator is controlled by an on/off signal or by a commercially available modulating or floating point control system and moves the ball of the ball valve – the throttling device – to the position preset by the control signal. Open the ball valve is carried out counterclockwise and close it clockwise. |
| Simple direct mounting | Tool-free snap assembly. |
| | The actuator can be plugged on the valve by hand (Caution! Just vertical movements). Pins must match the holes on the flange. |
| | The mounting orientation in relation to the valve can be selected in 180° increments. (Possible two times) |
| Installation notes | |

Ir

| Permissible installation orientation | The ball valve can be installed upright to horizontal. The ball valve may not be installed in a hanging position, i.e. with the stem pointing downwards. |
|--------------------------------------|---|
| | |
| Water quality requirements | Belimo valves are regulating devices. For the valves to function correctly in the long term, they must be kept free from particle debris (e.g. welding beads during installation work). The installation of a suitable strainer is recommended. |
| Servicing | Ball valves and rotary actuators are maintenance-free. |
| | Before any service work on the control element is carried out, it is essential to isolate the rotary actuator from the power supply (by unplugging the electrical cable if necessary). Any pumps in the part of the piping system concerned must also be switched off and the appropriate slide valves closed (allow all components to cool down first if necessary and always reduce the system pressure to ambient pressure level). |
| | The system must not be returned to service until the ball valve and the rotary actuator have been correctly reassembled in accordance with the instructions and the pipeline has been refilled by professionally trained personnel. |
| Flow direction | Direction of flow in both directions possible. |
| | |

100%

0%



Installation notes

The angle of rotation of the actuator can be changed by a clip in 2.5° increments. This is used Flow setting to set the kvs value (maximum flow rate of the valve).

Remove end stop clip and place at desired position.

After every change of the flow setting by means of end stop clip, an adaptation must be triggered on the modulating actuators.

Dimensions

| Туре Z2100QPF-К | DN 25 | Weight 0.60 lb [0.27 kg] | _ |
|---------------------------|---|--|---|
| | A B | | |
| | 5.5" [140] 5.6" [141 | | _ |
| | | | |
| | A B 5.5" [140] 5.5" [140] | C D E F 0] 3.4" [87] 2.6" [65] 0.9" [24] 0.9" [24] | _ |



Modulating, Electrical fail-safe, 24 V

- Nominal voltage AC/DC 24 V
- Control Modulating 2...10 V





Technical data

| | New York and the Research | |
|-----------------|------------------------------------|---|
| Electrical data | Nominal voltage | AC/DC 24 V |
| | Nominal voltage frequency | 50/60 Hz |
| | Nominal voltage range | AC 19.228.8 V / DC 21.628.8 V |
| | Power consumption in operation | 2.5 W |
| | Power consumption in rest position | 0.5 W |
| | Transformer sizing | 5 VA |
| | Electrical Connection | 22 GA plenum cable, 3 ft [1 m], with 1/2" NPT conduit connector |
| | Overload Protection | electronic thoughout 090° rotation |
| | Electrical Protection | actuators are double insulated |
| Functional data | Operating range Y | 210 V |
| | Operating range Y note | 420 mA w/ ZG-R01 (500 Ω, 1/4 W resistor) |
| | Position feedback U | 210 V |
| | Bridging time (PF) | 2 s |
| | Pre-charging time | 520 s |
| | Angle of rotation | 90° |
| | Angle of rotation note | adjustable with mechanical stop |
| | Running Time (Motor) | 75 s / 90° |
| | Running time fail-safe | <60 s |
| | Noise level, motor | 35 dB(A) |
| | Noise level, fail-safe | 35 dB(A) |
| | Position indication | pointer |
| Safety data | Power source UL | Class 2 Supply |
| | Degree of protection IEC/EN | IP40 |
| | Degree of protection NEMA/UL | NEMA 2 |
| | Enclosure | UL Enclosure Type 2 |
| | Agency Listing | cULus acc. to UL60730-1A/-2-14, CAN/CSA E60730-1:02 |
| | | CE acc. to 2014/30/EU and 2014/35/EU |
| | Quality Standard | ISO 9001 |
| | UL 2043 Compliant | Suitable for use in air plenums per Section 300.22(C) of the NEC and Section 602 of the IMC |
| | Ambient humidity | Max. 95% RH, non-condensing |
| | Ambient temperature | 35104°F [240°C] |
| | Storage temperature | -40176°F [-4080°C] |
| | | |



Technical data sheet

| Technical | data |
|-----------|------|

| Safety data | Servicing | maintenance-free | |
|-------------|------------------|-------------------|--|
| Weight | Weight | 0.55 lb [0.25 kg] | |
| Materials | Housing material | UL94-5VA | |

Product features

| Application | Electrical fail-safe proportional ZoneTight actuator. |
|-------------|--|
| | Valve selection should be done in accordance with the flow parameters and system specifications. The actuator is mounted directly to the valve without the need for tools or additional linkage. |
| | The actuator operates in response to a 210 V, 0.5 10 V or 420mA control signal. |

Electrical installation

X INSTALLATION NOTES

(A) Actuators with appliance cables are numbered.

Actuators may be connected in parallel. Power consumption and input impedance must be observed.

Actuators may also be powered by DC 24 V.

S Only connect common to negative (-) leg of control circuits.

- \bigwedge A 500 Ω resistor (ZG-R01) converts the 4...20 mA control signal to 2...10 V.
- Actuators with plenum cable do not have numbers; use color codes instead.

Meets cULus requirements without the need of an electrical ground connection.

\Lambda Warning! Live electrical components!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

Wiring diagrams

