Document No. 129-186 September 25, 2009

Flowrite[™] AP 599 Series 8-inch Pneumatic Valve Actuator

Product Description

The Flowrite AP 599 Series 8-inch Pneumatic Valve Actuator is designed for use with the Flowrite VF 599 Series Valves with a 3/4-inch (20 mm) stroke.

Product Numbers

599-01050

599-01051

Warning/Caution Notations

WARNING	A	Personal injury/loss of life may occur if a procedure is not performed as specified.
CAUTION	A	Equipment damage, or loss of data may occur if the user does not follow a procedure as specified.

Required Tools

24 mm open-end wrench

30 mm open-end wrench

3/8-inch, 3/4-inch, and 1-inch open-end wrenches

Expected Installation Time

55 minutes for field mounting of the actuator

90 minutes for removing the old and mounting a new actuator

Prerequisites



WARNING:

If mounting the actuator to a valve already in line, either close the shut-off valves in the piping (upstream first, then downstream) or switch off the pump to allow the differential and static pressure in the valve to drop.



CAUTION:

Do not damage or scratch the polished surface of the valve stem.




Figure 1. Acceptable Mounting Positions.

The vertical position is recommended for mounting. The acceptable mounting positions are shown in *Figure 1*.

Installation

Begin with the instructions of *Figure 6* if you are not replacing an existing actuator.

Removing an existing actuator from a valve




Figure 2.




Figure 3.





Figure 4.



Before mounting an actuator to a valve




Figure 6.





Figure 7.



NOTE: Be careful not to break the washer.




Figure 8.

Mounting an actuator to a valve





Figure 9.



Page 3 of 5 Siemens Industry, Inc.







Figure 11.










Figure 15. Spring Adjustment.

Spring Adjustment

The top edge of the stem nut indicates the valve stem position. The "0" marking on the actuator yoke indicates stem up position. The "1" mark indicates stem down position. See *Figure 15*.

With the actuator in an upright position and the stem visible as shown in *Figure 15*, use a 3/4-inch openend wrench to turn the adjustment screw.

- For Normally Open Valves: To increase the start to close pressure, turn the adjustment screw from right to left. To decrease, turn the adjustment screw from left to right.
- For Normally Closed Valves: To increase the start to open pressure, turn the adjustment screw from right to left. To decrease, turn the adjustment screw from left to right.

NOTE: As the line pressure differential across the valve increases, the spring span will decrease.

The installation is now complete.

Reference

Technical Instructions

Document Number

Flowrite AP 599 Series 8-inch Pneumatic Valve Actuator 155-161P25

Information in this publication is based on current specifications. The company reserves the right to make changes in specifications and models as design improvements are introduced. Flowrite is a trademark of Siemens Industry, Inc. Product or company names mentioned herein may be the trademarks of their respective owners. © 2009 Siemens Industry, Inc.