



Differential pressure sensor Air

Differential pressure transmitter with 8 selectable ranges and Modbus funtionality. For monitoring over-, under or the differential pressure of air and other non-flammable and non-aggressive gases. Typical application in HVAC systems for monitoring air filters, fans V-belts or fire and smoke control dampers. Options available with LCD display. NEMA 4X / IP65 rated enclosure.







Type Overview

Туре	Measuring range [Pa] [Pa]	Measuring range [inch WC] [inch WC]	Communication	Output signal active pressure	Output signal active volumetric flow	Burst pressure	Display type
22ADP-554	-1002500	-0.410	Modbus RTU	05 V, 010 V	05 V, 010 V	160 inch WC [40 kPa]	-
22ADP-554L	-1002500	-0.410	Modbus RTU	05 V, 010 V	05 V, 010 V	160 inch WC [40 kPa]	LCD

Technical data

Electrical Data	Nominal voltage	AC/DC 24 V		
	Remark about nominal voltage range	AC 1929 V / DC 1535 V		
	Power consumption AC	4.3 VA		
	Power consumption DC	2.3 W		
	Electrical connection	Pluggable spring loaded terminal block max. 2.5 mm²		
	Cable entry	Cable gland with strain relief 2x ø6 mm (1/2" NPT conduit adapter included)		
Data bus communication	Communication	Modbus RTU		
	Number of nodes	Modbus see interface description		
Functional Data	Sensor technology	piezo measuring element		
	Application	air		
	Multirange	8 measuring ranges selectable		
	Voltage output	2 x 05 V, 010 V, min. resistance 10 kΩ		
	Output signal active note	Output 05/10 V selectable with switch		
	Display	LCD, 1.14x1.38 in. [29x35 mm] with backlight		
		Measured values: Pa, inch WC (programmable) Measured values volumetric flow: m³/h, cfm (parametrisable)		
	Typical response time	adjustable 0.8 s or 4.0 s		
Measuring Data	Measured values	Differential pressure Volumetric flow		
	Measuring fluid	air and non-aggressive gases		



22ADP-554.

Technical data


Specification flow	Measuring range volumetric flow	Adjustable via Modbus Default setting: 0750'000 cfm Selectable units: m³/h, m³/s, cfm			
Specification pressure	Measuring range pressure settings	Setting	Range [Pa]	Range [inch WC]	Factory setting
		S0 S1 S2 S3 S4 S5	02500 02000 01500 01000 0500 0250	010 08 06 04 02 01	
		S6 S7	0100 -100100	00.4 -0.40.4	
	Accuracy	measurin	g range ≤2 i	nch WC: ±0.02 inch nch WC: ±0.04 inch	
	Long term stability	±2.5% FS0	O (Full Scale	Output) / 4 yr.	
Materials	Cable gland	PA6, blac	k		
	Housing	Cover: PC Bottom: F Seal: NBR UV resista UL94 5VA	PC, orange 70, black ant		
Safety Data	Protection class IEC/EN	III, Safety	v Extra-Low V	/oltage (SELV)	
	Power source UL	Class 2 Su	upply		
	Degree of protection IEC/EN	IP65			
	Degree of protection NEMA/UL	NEMA 4X			
	Enclosure	UL Enclos	ure Type 4X		
	EU Conformity	CE Markir	ng		
	Certification IEC/EN		0730-1 and I	EC/EN 60730-2-6	
	Quality Standard	ISO 9001			
	UL 2043 Compliant			plenums per Secti and Section 602 of	
	Type of action	Type 1			
	Rated impulse voltage supply	0.8 kV			
	Pollution degree	3			
	Ambient humidity	Max. 95%	RH, non-co	ndensing	
	Ambient temperature	-1050°C	[15122°F]		
	Fluid temperature	-1050°C	[15122°F]		
	Storage temperature	-4176°F	[-2080°C]		



Safety Notes

Safety Notes	
<u> </u>	This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorized modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.
	Ensure all power is disconnected before installing. Do not connect to live/operating equipment.
	Only authorized specialists may carry out installation. All applicable legal or institutional installation regulations must be complied with during installation.
	The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.
Remarks	
Manual zero-point calibration	In normal operation zero-point calibration should be executed every 12 months.
	Attention! For executing zero-point calibration, the power supply must be connected one hour before.
	• Release both tube connectors from the pressure ports + and -
	• Press the button "Manual zero-point calibration" until the LED lights permanently
	• Wait until the LED flashes again and reinstall the tube connectors to the pressure ports (note + and -)
Indicators and Operation	
Indicators	Depending on the device and the number of measured values, the display automatically scales.

ators Depending on the device and the number of measured values, the display automatically scales. Parameters, such as the fading in/out of measured values, brightness and traffic light function, are changed via the app or bus system. During the boot process, the software and hardware versions are displayed.



Parts included

Description	Туре
Mounting plate L housing	A-22D-A10
Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP	A-22AP-A08
Cable Gland with strain relief ø68 mm Dowels	
Screws	
1/2" NPT conduit adapter, 2x ø6 mm	



Accessories			
C	optional accessories	Description	Туре
		Pitot tube, Metal, L 1.5", Tube connection 0.2"	A-22AP-A01
	Taola	Pitot tube, Metal, L 4", Tube connection 0.2"	A-22AP-A03
	Tools	Description Belimo Duct Sensor Assistant App	Type Belimo Duct
			Sensor Assistant
			App
		Bluetooth dongle for Belimo Duct Sensor Assistant App	A-22G-A05
		* Bluetooth dongle A-22G-A05 Certified and available in North America, European Union, EFTA States a	ad LIK
Service			
	Tools connection	This sensor can be operated and parametrized using the Belimo Assistar	nt App.
		When using the Belimo Duct Sensor Assistant App, the Bluetooth dongle communication between the app and the Belimo sensor.	is required to enable
	For the standard operation and parametrization of the sensor the Bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with factory default settings shown above.		
		Requirement:	
		- Bluetooth dongle (Belimo Part No: A-22G-A05)	
		- Bluetooth-capable smartphone	
		- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)	
		Procedure:	
		- Plug the Bluetooth dongle into the sensor via the Micro-USB connector interface PCB	or by means of the
		- Connect Bluetooth-capable smartphone with Bluetooth dongle	
		- Select parametrization in the Belimo Assistant App	


Wiring Diagram



Supply from isolating transformer.

The wiring of Modbus RTU (RS-485) is to be carried out in accordance with applicable regulations (www.modbus.org). The device has switchable resistors for bus termination. Modbus-GND: Supply and communication are not galvanically isolated. Connect earth signal of the devices with one another.





Detailed documentation

The separate document Sensor Modbus-Register informs about Modbus register, addressing, parity and bus termination (DIP1: address, DIP2: baud rate, parity, bus termination)


In addition to the information on the bus, the following analog outputs are available:

AOU1: differential pressure

AOU2: volumetric flow


The volumetric flow is calculated from the differential pressure, the k-factor and the height. Factory setting for the k-factor is 1.00 and for the height 330 metres above sea level. The values of the k-factor and the height can be changed via bus system.


Wiring RS485 Modbus RTU





Dimensions





Туре	Weight
22ADP-554	0.90 lb [0.41 kg]
22ADP-554L	0.95 lb [0.43 kg]

Further documentation

- Modbus Interface description
- Installation instructions