

G220S, 2-Way, Globe Valve, Stainless Steel Trim



 P E
WARRANTY

Technical Data	
Service	chilled or hot water, up to 60% glycol,
	steam
Flow Characteristic	linear
Controllable Flow Range	stem up - open A to AB
Size [mm]	0.75" [20]
End Fitting	NPT female ends
Body	bronze
Stem	316 stainless steel
Stem Packing	spring loaded Teflon® V-ring
Seat	316 stainless steel
Plug	316 stainless steel
Disc	Teflon
Body Pressure Rating [psi]	ANSI 250
ANSI Class	ANSI 250 (up to 400 psi below 150°F)
Max Inlet Pressure (Steam)	100 psi (690 kPa)
Media Temperature Range (Water)	20°F to 280°F [-7°C to 138°C]
Media Temperature Range (Steam)	32°F to 338°F [0°C to 170°C]
Maximum Differential Pressure (Steam)	35 psi
Max Differential Pressure (Water)	35 psi (241 kPa)
Rangeability	60:1
Cv	7.5
Weight	2.2 lb [1 kg]
Leakage	ANSI Class IV
Servicing	Repack/Rebuild kits available



Application

This valve is typically used in Air handling units on heating or cooling coils, and fan coil unit heating or cooling coils. Some other common applications include Unit Ventilators, VAV box re-heat coils and bypass loops. This valve is suitable for use in hydronic system with variable flow. Bronze and stainless steel trim valves can be used for steam applications, depending on actuator and close-off combinations.

Suitable Actuators				
	Non-Spring	Spring	Electronic Fail-Safe	
G220S	LVB(X)	LF	LVKB(X)	



Piping

The valves should be mounted in a weather-protected area in a location that is within the ambient limits of the actuator. Allow sufficient room for valve with actuator and for service. The G2(S) and G3(D) preferred mounting position of the valve is with the valve stem vertical above the valve body, for maximum life. However, the assemblies can be mounted with the valve stem vertical or horizontal in relation to the pipe. The actuators should never be mounted underneath the valve, as condensation can build up and result in a failure of the actuators. Do not reverse flow direction.



G220S, 2-Way, Globe Valve, Stainless Steel Trim





LF24-SR US, Valve Actuator Modulating, Spring Return, 24 VAC for 2 to 10 VDC or 4 to 20 mA Control Signal





|--|

Technical Data		
Power Supply	24 VAC ± 20%, 50/60 Hz, 24 VDC ± 10%	
Power Consumption Running	2.5 W	
Power Consumption Holding	1 W	
Transformer Sizing	5 VA (class 2 power source)	
Electrical Connection	3ft [1m], 18 GA plenum cable with 1/2"	
	conduit connector	
Overload Protection	electronic throughout 0° to 95° rotation	
Operating Range Y	2 to 10 VDC, 4 to 20 mA w/ ZG-R01 (500 Ω,	
	1/4 W resistor)	
Input Impedance	100 k Ω for 2 to 10 VDC (0.1 mA), 500 Ω for	
	4 to 20 mA	
Feedback Output U	2 to 10 VDC (max 0.7 mA) for 95°	
Angle of Rotation	90°	
Direction of Rotation (Motor)	reversible with built-in switch	
Direction of Rotation (Fail-Safe)	reversible with CW/CCW mounting	
Position Indication	visual indicator, 0° to 95° (0° is full spring	
	return position)	
Running Time (Motor)	150 sec constant, independent of load	
Running Time (Fail-Safe)	<25 sec @ -4°F to 122°F [-20°C to 50°C], <	
	60 sec @ -22°F [-30°C]	
Ambient Temperature Range	-22°F to 122°F [-30°C to 50°C]	
Storage Temperature Range	-40°F to 176°F [-40°C to 80°C]	
Housing	NEMA 2, IP54	
Agency Listings†	cULus acc. To UL 873 and CAN/CSA C22.2	
	No. 24-93	
Noise Level (Motor)	<50 dB (A)	
Noise Level (Fail-Safe)	<62 dB (A)	
Servicing	maintenance free	
Quality Standard	ISO 9001	

†Rated Impulse Voltage 800V, Type of action 1.AA, Control Pollution Degree 3



Wiring Diagrams

 \wedge

 $\sqrt{3}$

 $\sqrt{5}$

/11\

🔀 INSTALLATION NOTES

Actuators with appliance cables are numbered.

Provide overload protection and disconnect as required.

Actuators may also be powered by 24 VDC.

Only connect common to negative (-) leg of control circuits.

A 500 Ω resistor (ZG-R01) converts the 4 to 20 mA control signal to 2 to 10 VDC.

Actuators may be connected in parallel if not mechanically linked. Power consumption and input impedance must be observed.

Meets cULus requirements without the need of an electrical ground connection.

WARNING! LIVE ELECTRICAL COMPONENTS!

During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

