

## Differential pressure sensor Air

Differential pressure transmitter with 8 selectable ranges and BACnet functionality. For monitoring over-, under or the differential pressure of air and other non-flammable and non-aggressive gases. Typical application in HVAC systems for monitoring air filters, fan Vbelts or fire dampers and smoke control dampers. Options available with LCD display. IP65 / NEMA 4X rated enclosure.

## Technical data sheet

# 22ADP-564L





### **Type Overview**

	Туре	Measuring range pressure [Pa]	range pressure [inch WC]	Communication	Output signal active pressure	TIOW	Burst pressure	Display type
	22ADP-564L	1002500	-0.410	BACnet MS/TP	05 V, 010 V	05 V, 010 V	160 inch WC [40 kPa]	LCD
Technical data								
Electrical Data	Nominal vo	ltage		AC/I	DC 24 V			
	Nominal voltage range			AC 1929 V / DC 1535 V				
		Power consumption AC			4.3 VA			
Power consur				2.3 W				
Electrical connection			Pluggable spring loaded terminal block max. 2.5 mm²					
	Cable entry					ith strain rel dapter inclue		m (1/2"
Data bus communication	Communication		BACnet MS/TP					
	Number of	nodes		BAC	net see in	terface descr	ription	
Functional Data	Sensor Technology Application Multirange		piezo measuring element					
			air					
			8 measuring ranges selectable					
	Voltage output		2x 0	$2x$ 05 V, 010 V, min. resistance 10 $k\Omega$				
	Output signal active note		•	Output 05/10 V selectable with switch				
	Display			LCD, 1.14x1.38 in. [29x35 mm] With backlight				
						ues: Pa, inch	WC (program	nmahle)
						ues volumetr		
	(parametrisable) Response time adjustable 0.8 s or 4.0 s		le)					
			adjustable 0.8 s or 4.0 s					
Measuring Data	Measuring Data Measured values		Differential pressure					
	Measuring fluid			air and non-aggressive gases				



## Technical data sheet

22ADP-564L

Measuring Data	Measuring range pressure settings	Setting	Range [Pa]	Range [inch WC]	Factory setting	
		S0	02500	010		
		S1	02000	08		
		S2	01500	06		
		S3	01000	04		
		S4	0500	02		
		S5	0250	01		
		S6 S7	0100 -100100	00.4 -0.40.4		
	Accuracy pressure		measuring range ≤2 inch WC: ±0.02 inch WC measuring range >2 inch WC: ±0.04 inch WC ±2.5% FSO (Full Scale Output) / 4 yr.			
	Long-term stability	±2.5% F				
Materials	Cable gland	PA6, bla	PA6, black			
	Housing	Cover: PC, orange Bottom: PC, orange				
			Seal: NBR70, black			
		UV resistant				
Safety Data	Ambient humidity	Max. 95	Max. 95% RH, non-condensing			
	Ambient temperature		-1050°C [15122°F]			
	Fluid temperature	-1050°	°C [15122°F]	]		
	Protection class IEC/EN	ower source UL Class 2 Supply		/oltage (SELV)		
	Power source UL					
	EU Conformity					
	ertification IEC/EN IEC/EN 60730-1 and		50730-1 and I	EC/EN 60730-2-6		
	Certification UL		cULus acc. to UL60730-1A/-2-6, CAN/CSA E60730-1		A	
	Degree of protection IEC/EN	IP65				
	Degree of protection NEMA/UL	NEMA 4	NEMA 4X			
	Enclosure	UL Enclosure Type 4X				
	Quality Standard	ISO 900	01			
Mode of operation		Type 1				
	Pollution degree	3				
	Rated impulse voltage supply	0.8 kV				
	Construction Independently mounted			ted control		

#### Safety Notes



This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorized modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorized specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.



22ADP-564L



Remarks				
Manual zero-point calibration	In normal operation zero-point calibration should be executed every 12 months. Attention! For executing zero-point calibration the power supply must be connected one hour before. • Release both connection tubes from the pressure terminals + and - • Press the button until the LED lights permanently • Wait until the LED flashes again and reinstall the connection tubes to the pressure ports (note + and -)			
Operating controls and indicators				
Indicator elements	Depending on the device and the number of measured values, the display automatically scales. Parameters, such as the fading in/out of measured values, brightness and traffic light function, are changed via the app or bus system. During the boot process, the software and hardware versions are displayed.			
0000	1 Fault / sensor failure			
	2 Service / visual inspection due			
<b>∮→<u>A X B                                  </u></b>	<b>3</b> TLF (traffic light function) active (thresholds for display colour changes)			
$6 \longrightarrow dP \star \mathbf{Pa} $	4 Radio active (not available)			
$\mathbf{B} \longrightarrow 100$ $5$ Status bar				
	6 Measured value (* appears when TLF function is activated for this value)			
	<b>7</b> Unit of measure			
8 Measured value				
Scope of delivery				
Scope of delivery	Description	Туре		
	Mounting plate L housing Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP	A-22D-A10 A-22AP-A08		
	Cable Gland with strain relief Ø68 mm Dowel Screws			
	1/2" NPT conduit adapter, 2 x Ø6 mm			

## Accessories

Optional accessories	Description	Туре		
	Pitot tube, Metal, L 1.5", Tube connection 0.2"	A-22AP-A01		
	Pitot tube, Metal, L 4", Tube connection 0.2"	A-22AP-A03		



bervice

**Service tools connection** This sensor can be operated and parametrized using the Belimo Assistant App.

When using the Belimo Duct Sensor Assistant App, the Bluetooth dongle is required to enable communication between the app and the Belimo sensor.

For the standard operation and parametrization of the sensor the Bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with the factory default settings shown above.


**Requirement:** 

- Bluetooth dongle (Belimo Part No: A-22G-A05)
- Bluetooth-capable smartphone
- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)

Procedure:

- Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB

- Connect Bluetooth-capable smartphone with Bluetooth dongle
- Select parametrization in the Belimo Assistant App



#### Wiring Diagram




**Notes** Supply from isolating transformer.

The wiring of the line for BACnet (MS/TP) has to be carried out in accordance with applicable RS485 regulations.

BACnet GND: Supply and communication are not galvanically isolated. Connect earth signal of the devices with one another.

## 22ADP-564L





**Detailed documentation** 

The separate document, BACnet PICS, informs about the PICS, MAC addressing and bus termination (DIP1 & DIP2).

In addition to the information on the bus, the following analog outputs are available:

AOU1: differential pressure

AOU2: volumetric flow

The volumetric flow is calculated from the differential pressure, the k-factor and the height. Factory setting for the k-factor is 1.00 and for the height 330 metres above sea level. The values of the k-factor and the height can be changed via bus system.

#### Wiring RS485 BACnet MS/TP

