

Differential pressure sensor Air

Differential pressure transmitter with 8 selectable ranges and BACnet functionality. For monitoring over-, under or the differential pressure of air and other non-flammable and non-aggressive gases. Typical application in HVAC systems for monitoring air filters, fan Vbelts or fire dampers and smoke control dampers. Options available with LCD display. IP65 / NEMA 4X rated enclosure.

Technical data sheet







5-year warranty





Type Overview

Type	Measuring range pressure [Pa]	range	Communication	active	Output signal active volumetric flow	nressure	Display type	/Additional features
22ADP-56Q	-150250	-0.61	BACnet MS/TP	•	05 V, 010 V	160 inch WC [40 kPa]	-	-
22ADP-56QB	3-150250	-0.61	BACnet MS/TP	05 V, 010 V	05 V, 010 V	160 inch WC [40 kPa]	LCD	Auto-Zero

Technical data		
Electrical Data	Nominal voltage	AC/DC 24 V
	Nominal voltage range	AC 1929 V / DC 1535 V
	Power consumption AC	4.3 VA
	Power consumption DC	2.3 W
	Electrical connection	Pluggable spring loaded terminal block max. 2.5 mm²
	Cable entry	Cable gland with strain relief 2 x Ø6 mm (1/2" NPT conduit adapter included)
Data bus communication	Communication	BACnet MS/TP
	Number of nodes	BACnet see interface description
Functional Data	Sensor Technology	piezo measuring element
	Application	air
	Multirange	8 measuring ranges selectable
	Voltage output	2x 05 V, 010 V, min. resistance 10 kΩ
	Output signal active note	Output 05/10 V selectable with switch
	Display	
		LCD, 1.14x1.38 in. [29x35 mm] With backlight
		Measured values: Pa, inch WC (programmable)
		Measured values volumetric flow: m³/h, cfm
		(parametrisable)
	Response time	adjustable 0.8 s or 4.0 s
Measuring Data	Measured values	Differential pressure
	Measuring fluid	air and non-aggressive gases



Technical data sheet			22ADP-	56Q	
Measuring range pressure settings	Setting	Range [Pa]	Range [inch WC]	Factory setting	
	S0	0250	01	Jetting	
	S1	0100	00.4	•	
	S2	050	00.2		
	S3	025	00.1		
	S4	-2525			
		_			
Long-term stability	±2.5% F	SO (Full Scale	Output) / 4 yr.		
Cable gland	PA6, bla	ck			
Housing	Cover: P	C, orange			
		•			
	UV resis	tant			
Ambient humidity	Max. 95	% RH, non-co	ndensing		
Ambient temperature	-1050°	°C [15122°F]			
Fluid temperature	-1050°	°C [15122°F]]		
Protection class IEC/EN	III, Safe	ty Extra-Low \	/oltage (SELV)		
Power source UL	Class 2 S	2 Supply			
EU Conformity	CE Mark	ing			
Certification IEC/EN	IEC/EN 6	50730-1 and I	EC/EN 60730-2-6		
Certification UL			0-1A/-2-6, CAN/CS/	4	
Degree of protection IEC/EN	IP65				
Degree of protection NEMA/UL	NEMA 4	X			
Enclosure	UL Enclo	sure Type 4X			
Quality Standard	ISO 900	1			
Mode of operation	Type 1				
Pollution degree	3				
Rated impulse voltage supply	0.8 kV				
	Accuracy pressure Long-term stability Cable gland Housing Ambient humidity Ambient temperature Fluid temperature Protection class IEC/EN Power source UL EU Conformity Certification IEC/EN Certification UL Degree of protection NEMA/UL Enclosure Quality Standard Mode of operation Pollution degree	Measuring range pressure settings So	Measuring range pressure settings Setting Range [Pa] SO 0250 S1 0100 S2 050 S3 025 S4 -2525 S5 -5050 S6 -100100 S7 -150150 Accuracy pressure ±0.004 inch WC @ rar Long-term stability ±2.5% FSO (Full Scale Cable gland PA6, black Housing Cover: PC, orange Bottom: PC, orange Seal: NBR70, black UV resistant Ambient humidity Max. 95% RH, non-co Ambient temperature -1050°C [15122°F] Fluid temperature -1050°C [15122°F] Protection class IEC/EN III, Safety Extra-Low N Power source UL Class 2 Supply EU Conformity CE Marking Certification IEC/EN IEC/EN 60730-1 and I Certification UL CULus acc. to UL6073 E60730-1 Degree of protection IEC/EN IP65 Degree of protection NEMA/UL NEMA 4X Enclosure UL Enclosure Type 4X Quality Standard ISO 9001 Mode of operation Type 1 Pollution degree	Setting Range Pa Range Inch WC	

Safety Notes



Construction

This device has been designed for use in stationary heating, ventilation and air-conditioning systems and must not be used outside the specified field of application. Unauthorized modifications are prohibited. The product must not be used in relation with any equipment that in case of a failure may threaten humans, animals or assets.

Independently mounted control

Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Only authorized specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.

The device contains electrical and electronic components and must not be disposed of as household refuse. All locally valid regulations and requirements must be observed.

Remarks

Automated zero-point calibration (Auto Zero)

Transmitters equipped with the auto-zero calibration are maintenance-free.

The auto-zero calibration electronically adjusts the transmitter zero every 10 minutes. The function eliminates all output signal drift due to thermal, electronic or mechanical effects. The auto-zero adjustment takes approx. 4 seconds after which the device returns to its normal measuring mode. During the 4 second adjustment period, the output and display values will freeze to the latest measured value.

Manual zero-point calibration

In normal operation zero-point calibration should be executed every 12 months.


Attention! For executing zero-point calibration the power supply must be connected one hour before.

- Release both connection tubes from the pressure terminals + and -
- Press the button until the LED lights permanently
- Wait until the LED flashes again and reinstall the connection tubes to the pressure ports (note
- + and -)

Operating controls and indicators

Indicator elements

Depending on the device and the number of measured values, the display automatically scales. Parameters, such as the fading in/out of measured values, brightness and traffic light function, are changed via the app or bus system. During the boot process, the software and hardware versions are displayed.



- 1 Fault / sensor failure
- 2 Service / visual inspection due
- 3 TLF (traffic light function) active (thresholds for display colour changes)
- Radio active (not available)
- Status bar
- 6 Measured value (* appears when TLF function is activated for this value)
- Unit of measure
- 8 Measured value

Scope of delivery

Description	Туре		
Mounting plate L housing	A-22D-A10		
Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP	A-22AP-A08		
Cable Gland with strain relief Ø68 mm Dowel Screws			
	Mounting plate L housing Duct connector kit, PVC tube 2 m, 2 connection elements (Plastic) for 22ADP Cable Gland with strain relief Ø68 mm Dowel		

Accessories

Optional accessories	Description	Туре
	Pitot tube, Metal, L 1.5", Tube connection 0.2"	A-22AP-A01
	Pitot tube, Metal, L 4", Tube connection 0.2"	A-22AP-A03



Service

Service tools connection

This sensor can be operated and parametrized using the Belimo Assistant App.

When using the Belimo Duct Sensor Assistant App, the Bluetooth dongle is required to enable communication between the app and the Belimo sensor.


For the standard operation and parametrization of the sensor the Bluetooth dongle and the Belimo Duct Sensor Assistant App are not needed. The sensor will arrive pre-configured with the factory default settings shown above.

Requirement:

- Bluetooth dongle (Belimo Part No: A-22G-A05)
- Bluetooth-capable smartphone
- Belimo Duct Sensor Assistant App (Google Play & Apple App Store)

Procedure:

- Plug the Bluetooth dongle into the sensor via the Micro-USB connector or by means of the interface PCB
- Connect Bluetooth-capable smartphone with Bluetooth dongle
- Select parametrization in the Belimo Assistant App



Wiring Diagram

Notes


Supply from isolating transformer.



The wiring of the line for BACnet (MS/TP) has to be carried out in accordance with applicable RS485 regulations.

BACnet GND: Supply and communication are not galvanically isolated. Connect earth signal of the devices with one another.





① Button
② red: Error
③ yellow: Tx
④ yellow: Rx
⑤ and ⑥ Status LED
* Factory setting
P Pressure unit
T Response time
U Output signal

Detailed documentation

The separate document, BACnet PICS, informs about the PICS, MAC addressing and bus termination (DIP1 & DIP2).

In addition to the information on the bus, the following analog outputs are available:

AOU1: differential pressure


AOU2: volumetric flow

The volumetric flow is calculated from the differential pressure, the k-factor and the height.

Factory setting for the k-factor is 1.00 and for the height 330 metres above sea level.


The values of the k-factor and the height can be changed via bus system.


Wiring RS485 BACnet MS/TP





Dimensions





туре	weight		
22ADP-56Q	0.90 lb [0.41 kg]		
22ADP-56QB	0.97 lb [0.44 kg]		