Potable water valve, 2-way, internal thread

- For potable water applications
- NSF/ANSI 372 Lead Free
- NSF/ANSI 61 Water Quality







EXT-B2075-PWV-NPT

2-year warranty



Technical data

Valve Size	0.75" [20]
Potable water certificate	NSF/ANSI 61 NSF/ANSI 372
Fluid	Potable water
Fluid temperature	-4212°F [-20100°C]
Body Pressure Rating	600 psi CWP
Close-off pressure Δps	200 psi
Differential pressure Δpmax	200
Angle of rotation	90°
Pipe connection	NPT female
Servicing	maintenance-free
Flow Pattern	2-way
Leakage rate	0%
Cv	49
Valve body	Lead free brass

Materials

Value hadu	Lead free brass	
Valve body	read tree prass	
Stem	Lead free brass	
Seat	PTFE	
O-ring	EPDM	
Ball	Chrome plated lead free brass	
Non-Spring	LRB(X)	
Spring	IF	

Suitable actuators

S	Non-Sprin	
	Carina	

Safety notes



The ball valve has to be exercised at least once a week, so that the quality of potable water as well as the functionality are not affected.

Product features

Mode of operation

The on/off ball valve is adjusted by a rotary actuator. The rotary actuator is connected by an on/off signal. Open the ball valve counterclockwise and close it clockwise.

Installation notes


Notes

The ball valve is a regulating device. To fulfil this control task in the long term, the circuit must be kept free from particle debris (e.g. welding beads during installation work).

Recommended installation positions


The ball valve can be installed upright to horizontal. The ball valve may not be installed in a hanging position, i.e. with the stem pointing downwards.





Servicing Ball valves and rotary actuators are maintenance-free.

Dimensions



On/Off, Floating Point, Non-Spring Return, 24 V





Technical data

Electrical data	Nominal voltage	AC/DC 24 V
	Nominal voltage frequency	50/60 Hz
	Power consumption in operation	1.5 W
	Power consumption in rest position	0.2 W
	Power consumption for wire sizing	2 VA
	Transformer sizing	2.5 VA (class 2 power source)
	Auxiliary switch	1 x SPDT, 3 A resistive (0.5 A inductive) @ AC 250 V adjustable 0100%
	Switching capacity auxiliary switch	3 A resistive (0.5 A inductive) @ AC 250 V
	Electrical Connection	18 GA plenum cable, 3 ft [1 m], with 1/2" conduit connector
	Overload Protection	electronic thoughout 090° rotation
Functional data	Input Impedance	600 Ω
	Direction of motion motor	selectable with switch 0/1
	Manual override	external push button
	Angle of rotation	90°
	Angle of rotation note	adjustable with mechanical stop
	Running Time (Motor)	90 s
	Noise level, motor	35 dB(A)
	Position indication	Mechanically, pluggable
Safety data	Degree of protection IEC/EN	IDE A

Safety data

Degree of protection IEC/EN	IP54
Degree of protection NEMA/UL	NEMA 2 UL Enclosure Type 2
Agency Listing	cULus acc. to UL60730-1A/-2-14, CAN/CSA E60730-1:02, CE acc. to 2014/30/EU and 2014/35/ EU; Listed to UL 2043 - suitable for use in air plenums per Section 300.22(c) of the NEC and Section 602.2 of the IMC
Quality Standard	ISO 9001
Ambient temperature	-22122°F [-3050°C]
Storage temperature	-40176°F [-4080°C]
Ambient humidity	max. 95% r.H., non-condensing
Servicing	maintenance-free
Weight	1.4 lb [0.60 kg]

Electrical installation



Weight

INSTALLATION NOTES

Provide overload protection and disconnect as required.

Actuators may be connected in parallel. Power consumption and input impedance must be observed.

Technical data sheet LRB24-3-S

Actuators may also be powered by DC 24 V.

Actuators Hot wire must be connected to the control board common. Only connect common to neg. (-) leg of control circuits. Terminal models (-T) have no-feedback.

Actuators with plenum cable do not have numbers; use color codes instead.

One built-in auxiliary switch (1x SPDT), for end position indication, interlock control, fan startup, etc.


Apply only AC line voltage or only UL-Class 2 voltage to the terminals of auxiliary switches. Mixed or combined operation of line voltage/safety extra low voltage is not allowed.

N


Meets cULus requirements without the need of an electrical ground connection.

Warning! Live electrical components!


During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.




On/Off




Floating Point - Triac Source



Auxiliary Switches



Floating Point



Floating Point - Triac Sink